



Ref #	Part Number	Qty	Description
1	MU92387		Seat
2	MU56516E700		Hinge, Seat
3	MU28X64		Retainer
4	MU18X16		Lockwasher
5	MU1X45		Bolt, Hex
6	MU91963 Z		Plate, Seat Switch
7	MU164X26		Spring, Compression
8	MU91822		Glide, Seat Spring
9	MU9X38		Bolt, Shoulder
10	MU91964		Spring, Seat
11	MU15X88		Locknut, Flange
12	MU56518E700		Bracket, Seat Pivot
13	MU28X23		Cap, Push On
14	MU56537 Z		Rod, Seat Hinge
15	MU56519E700		Support, Seat
16	MU26X249		Screw
17	MU2X53		Bolt, Carriage
18	MU54764E549		Panel, Right Side
19	MU54763E549		Panel, Left Side
20	MU94353		Cover, Steering Column
21	MU54747E549		Bracket, Panel
22	MU26X270		Screw, Tapping
23	MU690556		Panel, Control
24	MU26X201		Screw
25	MU56247		Throttle Control
26	MU56405E549		Console
27	MU56407E549		Cap, Front Console
28	MU94352		Cover, Lower Console
29	MU28X52		Retainer
30	MU28X18		J-Nut
31	MU56235E549		Panel, Front
32	MU91330		Screw, Southco
33	MU56406E549		Panel, Left Access
34	MU56022		Bearing, Steering Post
35	MU56233E700		Bracket, Cover Mounting
36	MU26X250		Screw
37	MU56122E700		Support, Body
38	MU9X29		Bolt, Shoulder
39	MU19X6		Lockwasher
40	MU26X49		Screw
41	MU15X84		Locknut, Flange
42	MU54800 Z		Clamp Assembly, Battery
43	MU17X38 Z		Washer
44	MU56240E700		Support, Steering Column
45	MU92637		Mat, Left
46	MU92636		Mat, Right
47	MU56612E549		Frame
48	MU6X74		Screw
49	MU15X66		Locknut
50			Engine
51	MU25X7		Bolt, Engine Mount
56	MU92317		Cap, Fuel
57	MU55805		Tank, Fuel
58	MU26X213		Screw, Hex
59	MU95197		Clamp, Hose
60	MU91022		Line, Fuel
61	MU55806E700		Bracket, Remote Tank (Front)
62	MU91174		Clamp, Gas Line

Ref #	Part Number	Qty	Description
63	MU56002		Filter, Fuel
64	MU54782E549		Panel, Rear
65	MU94941		Bracket, Remote Tank (Rear)
	MUF-000607J		Instruction Book & Parts List
	MU130006		Decal, Left Panel
	MU130007		Decal, Right Panel
	MU44X4741		Decal, Shift
	MU44X7325		Decal, Front Console Warning




Ref #	Part Number	Qty	Description
1	MU91031		Switch, Seat Sensor
2	MU15X66		Locknut
3	MU1X38		Bolt, Hex
4			Battery
5	MU24X3		Cable, Battery Ground (Black)
6	MU26X249		Screw
7	MU24X24		Cable, Positive Battery (Red)
8	MU91488		Cap, Ignition Switch
9	MU94613		Solenoid
10	MU91489		Nut, Ignition Switch
12	MU21064		Switch, Ignition
13	MU21079		Key, Ignition
14	MU250X84		Harness, Wire
15	MU54212		Fuse
16	MU407078		Holder, Fuse
17	MU91032		Switch, Attachment Clutch
18	MU26X233		Screw
19	MU24273		Switch, Limit
22	MU54148		Cover, Terminal
23	MU91896		Tray, Battery




Ref #	Part Number	Qty	Description
1	MU15X88		Locknut, Flange
3	MU93349		Guide, Belt
4	MU56610E700		Shifter Assembly
5	MU15X84		Locknut, Flange
6	MU26X267		Screw
7	MU91573		Grip, Shift Lever
8	MU15X79		Hex Nut
9	MU165X100		Spring, Extension
10	MU30X20		Pin, Cotter
11	MU17X53 Z		Washer
12	MU1X38		Bolt, Hex
13	MU56595E700		Plate, Index
14	MU56606E700		Gate, Shift
15	MU56529E700		Brace, Shift Gate
16	MU15X89		Locknut, Flange
17	MU56519E549		Support, Seat
18	MU55873		Grip, Parking Brake
20	MU55825		Pedal
22	MU56612E549		Frame Assembly
23	MU1X124		Bolt, Hex
25	MU1X145		Bolt, Hex
26	MU18X32		Lockwasher
27	MU17X36 Z		Washer
28	MU56500 Z		Yoke, Brake
29	MU21920		Nut, Adjusting
30	MU56505 Z		Yoke, Shift
31	MU17X47 Z		Washer
32	MU56591 Z		Rod, Shift
33	MU17X174HT		Washer, Hardened
34	MU56530 Z		Rod, Brake
35	MU56410 Z		Rod, Parking Brake
36	MU165X85		Spring, Extension
37	MU56511E700		Lever, Pedal
38	MU56224E700		Plate, Left Suspension
39	MU56023E700		Plate, Right Suspension
40	MU56565 Z		Link, Parking Brake
41	MU165X107		Spring, Extension
42	MU30X50		Pin, Cotter
43	MU17X46 Z		Washer
44	MU56531 Z		Rod, Clutch
45	MU56227E700		Stop, Parking Brake
47	MU56623		Grommet
48	MU56641E700		Guide, Belt
49	MU26X49		Screw
50	MU92504 Z		Pulley Assembly, Stack
51	MU1X111		Bolt, Hex
52	MU11X7		Ring, Retainer
53	MU56562		Pulley, Drive
54	MU37X65		Belt, Motion Drive
55	MU56526		Pulley, Idler
56	MU17X170		Washer
57	MU19X35		Lockwasher
58	MU1X140		Bolt, Hex
59	MU1001034E700		Bracket, Idler
60	MU9X42		Bolt, Shoulder
61	MU165X81		Spring, Extension
62	MU15X43		Locknut, Hex
63	MU17X148		Washer

Ref #	Part Number	Qty	Description
64			Transaxle, Dana Model 4450-1
65	MU2X53		Bolt, Carriage
66	MU56503E700		Bracket, Transaxle
67	MU1X139		Bolt, Hex
68	MU17X160		Washer
69	MU56534		Key, Square
70	MU92308-601		Wheel & Tire Assembly
71	MU17X195		Washer
72	MU11X3		E-Ring
73	MU24373		Valve Stem Included with Key No. 70.
74	MU24393		Tire Only Included with Key No. 70.
75	MU94618		Hub Cap, Optional



Ref #	Part Number	Qty	Description
1	MU37X57		Belt, Mower Drive
2	MU91951		Pulley, Splined
3	MU18X33		Lockwasher
4	MU15X100		Locknut, Hex
5	MU15X41		Nut, Hex
6	MU690410		Pulley, Idler
7	MU55921E700		Bracket, Upper Idler
8	MU55895		Spacer
9	MU55979		Assembly, Blade Idler
10	MU15X88		Locknut, Flange
11	MU29X99		Pin, Clevis
12	MU24471 Z		Clevis
13	MU1X45		Bolt, Hex
14	MU31X6		Pin, Hair
15	MU55977		Guide, Belt
16	MU55920E700		Bracket, Lower Idler
17	MU2X53		Bolt, Carriage
18	MU15X79		Nut, Flange
19	MU55894		Guide, Belt
20	MU91925		Spacer
21	MU1X127		Bolt, Hex
22	MU55962		Housing, Mandrel
23	MU55956 Z		Guide, Belt
24	MU55974E700		Bracket, Hanger
25	MU164X1		Spring, Compression
26	MU15X43		Nut, Hex
27	MU166X4		Spring, Torsional
28	MU28X23		Push On Cap
29	MU21197 Z		Rod
30	MU56213E700		Hinge, Chute Deflector
31	MU17X91 Z		Washer
32	MU165X68		Spring, Extension
33	MU690369		Spacer
34	MU55916E700		Bracket, Front
35	MU26X216		Screw
36	MU1X75		Bolt, Hex
37	MU55971		Deflector, Chute
38	MU91921		Mandrel
39	MU92466		Adapter, Blade
40	MU17X166		Washer, Belleville
41	MU17X165		Washer, Hardened
42	MU15X100		Nut, Hex
43	MU90828 Z		Pin, Pull
44	MU17X67 Z		Washer
45	MU31X4		Pin, Hair
46	MU55793E701		Blade, Standard
51			UNKNOWN
1-51	MU403330		Mower Housing, Complete



Ref #	Part Number	Qty	Description
1	MU15X84		Locknut, Flange
2	MU17X53 Z		Washer
3	MU30X20		Pin, Cotter
4	MU26X249		Screw
5	0MU9X9 Z		Bolt, Shoulder
6	MU21920		Nut, Adjusting
7	MU92698		Grip, Blade Control
8	MU56031E700		Lever Assembly, Lift
9	MU91573		Grip, Lift Lever
10	MU55928 Z		Lever, PTO
11	MU1X76		Bolt, Hex
12	MU15X66		Locknut
13	MU15X89		Locknut, Flange
14	MU55853		Cam, Blade Control
15	MU56224E700		Plate, Left Suspension
16	MU26X249		Screw
17	MU15X88		Locknut, Flange
18	MU2X64		Bolt, Carriage
19	MU55326		Strut, Frame
20	MU55270E700		Plate, Mounting
21	MU55346E700		Rod Assembly, Rear Suspension
22	0MU9X4		Bolt, Shoulder
23	MU31X4		Pin, Hair
24	MU55344 Z		Plate, Adjusting
25	MU24839 Z		Rod, Lifter
27	MU55957E700		Rod, Suspension
28	MU24471 Z		Clevis
29	MU15X2		Nut, Hex
30	MU55271 Z		Link, Blade Drive
31	MU17X48		Washer
32	MU55930E700		Rod and Arm Assembly
33	MU165X67		Spring, Extension
34	MU55179 Z		Link, Front Deck
35	MU55139E700		Bracket, Front Suspension
36	MU56511E700		Lever, Pedal
37	MU17X122 Z		Washer
38	MU55298		Clevis
39	MU15X73		Locknut, Hex
40	MU9X17		Bolt, Shoulder
41	MU56023E700		Plate, Right Suspension
42	MU1X45		Bolt, Hex
43	MU56595E700		Plate, Index

Ref #	Part Number	Qty	Description
1	MU92078		Steering Wheel
3	MU1X102		Bolt, Hex
4	MU15X88		Locknut, Flange
5	MU56417 C		Post, Steering
6	MU15X88		Nut, Hex
7	MU17X47 Z		Washer
10	MU26X267		Screw
11	MU56224E700		Plate, Left Suspension
13	MU56023E700		Plate, Right Suspension
14	MU1X69		Bolt, Hex
15	MU56231E700		Support, Front Axle
16	MU30X49		Pin, Cotter
17	MU55003		Bearing, Spindle
19	MU56418		Gear, Pinion
20	MU56223E700		Axle Assembly, Front
21	MU56230E700		Hanger Assembly, Front Axle
22	MU55168		Bearing
23	MU56236E700		Sector Assembly
24	MU56625 Z		Rod, Drag Link
25	MU15X61		Nut, Hex
26	MU21031		Ball Joint, Steering
27	MU15X87 Z		Locknut, Flange
28	MU17X87 Z		Washer
30	MU17X53 Z		Washer
32	MU30X20		Pin, Cotter
34	MU55039E700		Spindle Assembly, Left
35	MU55026 Z		Rod, Tie
36	MU55038E700		Spindle Assembly, Right
37	MU56105		Bearing, Wheel Also included with Key No. 40.
38	MU55700		Tire
39	MU24373		Valve Stem Also included with Key No. 40.
40	MU92303-601		Wheel & Tire Assembly
41	MU17X197		Washer
42	MU94618		Cap, Hub (Optional)
43	MU56225E700		Bracket, Blade Drive
44	MU26X263		Screw