



Ref #	Part Number	Qty	Description
1	092387		Seat
2	56516E701		Hinge, Seat
3	028X64		Retainer
4	018X16		Lockwasher
5	001X45		Bolt, Hex
6	091963 Z		Plate, Seat Switch
7	164X26		Spring, Compression
8	091822		Glide, Seat Spring
9	009X38		Bolt, Shoulder
10	091964		Spring, Seat
11	015X88		Locknut, Flange
12	56518E701		Bracket, Seat Pivot
13	028X23		Cap, Push On
14	565372		Rod, Seat Hinge
15	56517E701		Support, Seat
16	26X249		Screw
17	002X53		Bolt, Carriage
18	55017E701		Support, Body Also included with Key No. 21.
19	26X214		Screw
20	056598		Throttle Control
21	054766E245		Body
22	26X201		Screw
23	056570E245		Console Assembly
24	26X201		Screw
25	056022		Bearing, Steering Post
26	055023E700		Console, Plate
27	004X24		Screw
28	028X18		J-Nut
29	056241 Z		Reflector
30	090082		Lens
31	015X66		Locknut
32	548002		Clamp, Battery
33	026X49		Screw
34	17X382		Washer
35	021268		Grommet
37	056107		Mat, Left
38	56611E245		Frame Assembly
39	056106		Mat, Right
40	002X53		Bolt, Carriage
41	055805		Tank, Fuel
42	26X213		Screw
43	55806E701		Bracket, Fuel Tank
44	056002		Filter, Fuel
45	091174		Clamp
46	091022		Line, Fuel
47	023713		Clamp
48	092317		Cap, Fuel
49	0019X6		Washer
50			Engine Parts are available from a Authorized Engine Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory
51	0025X7		Bolt, Engine Mount
53	090331		Muffler
54	01X117		Bolt
55	090333		Shield, Heat
58	56636E701		Shield, Heat
59	028X64		Washer

Ref #	Part Number	Qty	Description
60	001X91		Bolt
62	015X76		Locknut, Flange
	F-97631		Owner's Manual, English
	F-97631FR		Owner's Manual, French
	F-97631GR		Owner's Manual, German
	F-97632		Parts List
	44X7040		Decal, Right Panel
	44X7041		Decal, Left Panel
	44X4402		Decal, Shift
	44X6164		Decal, Front
	44X6816		Decal, Warning




Ref #	Part Number	Qty	Description
1	091031		Switch, Seat Sensor
2	015X66		Locknut
3	002X82		Bolt
4	091414		Battery
	093292		Acid, Battery (Electrolyte)
5	0024X3		Cable, Battery Ground
6	026X49		Screw
7	024X24		Cable, Red Battery
8	091488		Cap, Ignition
9	024285		Solenoid
10	091489		Nut, Hex
11	056049		Cover, Solenoid
12	091846		Switch, Ignition
13	020729		Key, Ignition
14	250X64		Harness, Chassis Wire
15	054212		Fuse
16	407078		Holder, Fuse
17	091032		Switch, Limit
18	26X233		Screw
19	024273		Switch, Limit
20	092372		Socket, Light
21	090084		Bulb, Light
22	054148		Cover, Terminal
23	091896		Tray, Battery
24	014X79		Wingnut




Ref #	Part Number	Qty	Description
1	015X88		Locknut, Flange
2	0164X1		Spring, Compression
3	055826		Guide, Belt
4	056610E701		Shifter Assembly
5	015X84		Locknut, Flange
6	26X267		Screw
7	091573		Grip, Shift Lever
8	15X115		Hex Nut
9	165X100		Spring, Extension
10	030X20		Pin, Cotter
11	17X532		Washer
12	001X38		Bolt, Hex
13	56595E701		Plate, Index
14	56606E701		Gate, Shift
15	56529E701		Brace, Shift Gate
16	015X89		Locknut, Flange
17	56517E701		Support, Seat
18	055873		Grip, Parking Brake
20	055825		Pedal, Rubber
22	56611E245		Frame Assembly
23	01X124		Bolt, Hex
25	01X145		Bolt, Hex
26	018X32		Lockwasher
27	017X36		Washer
28	565002		Yoke, Brake
29	021920		Nut, Adjusting
30	056505 Z		Yoke, Shift
31	17X472		Washer
32	056591 Z		Rod, Shift
33	17X174 Z		Washer, Hardened
34	056530 Z		Rod, Brake
35	056566 Z		Rod, Parking Brake
36	165X85		Spring, Extension
37	56511E701		Lever, Pedal
38	56224E701		Plate, Left Suspension
39	56023E701		Plate, Right Suspension
40	056565 Z		Link, Parking Brake
41	165X107		Spring, Extension
42	030X50		Pin, Cotter
43	017X46 Z		Washer
44	056531 Z		Rod, Clutch
45	56227E701		Stop, Parking Brake
47	056623		Grommet
48	056215 Z		Guide, Belt
49	026X49		Screw
50	092247SE		Pulley Assembly, Stack
51	01X111		Bolt, Hex
52	0011X7		Ring, Retainer
53	056562		Pulley, Drive
54	037X65		Belt, Motion Drive
55	056526		Pulley, Idler
56	17X170		Washer
57	019X35		Lockwasher
58	01X140		Bolt, Hex
59	1001034E700		Bracket, Idler
60	009X42		Bolt, Shoulder
61	165X81		Spring, Extension
62	015X43		Locknut, Hex


Ref #	Part Number	Qty	Description
63	17X148		Washer
64			Transaxle, Dana Model 4450-1 Parts are available from a Authorized Engine Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory
65	002X53		Bolt, Carriage
66	56503E701		Bracket, Transaxle
67	01X139		Bolt, Hex
68	17X160		Washer
69	056534		Key, Square
70	92308-601		Wheel & Tire Assembly
71	17X195		Washer
72	0011X3		E-Ring
73	024373		Valve Stem Also included with Key No. 70.
74	024393		Tire Only Also included with Key No. 70.
75	094618		Hub Cap, Optional



Ref #	Part Number	Qty	Description
1	037X57		Belt, Mower Drive
2	091951		Pulley, Splined
3	018X33		Lockwasher
4	15X100		Locknut, Hex
5	015X41		Nut, Hex
6	091178		Pulley, Idler
7	055921E700		Bracket, Upper Idler
8	055895		Spacer
9	55979E701		Assembly, Blade Idler
10	015X88		Locknut, Flange
11	029X99		Pin, Clevis
12	024471 Z		Clevis
13	001X45		Bolt, Hex
14	0031X6		Pin, Hair
15	55977E701		Guide, Belt
16	055920E701		Bracket, Lower Idler
17	002X53		Bolt, Carriage
18	015X79		Nut, Flange
19	55894E701		Guide, Belt
20	091925		Spacer
21	01X127		Bolt, Hex
22	055962		Housing, Mandrel
23	055956 Z		Guide, Belt
24	55974E701		Bracket, Hanger
25	0164X1		Spring, Compression
26	015X88		Nut, Hex
27	0166X4		Spring, Torsional
28	028X23		Push On Cap
29	021197 Z		Rod
30	56213E701		Hinge, Chute Deflector
32	165X68		Spring, Extension
34	55916E701		Bracket, Front
35	26X216		Screw
36	001X75		Bolt, Hex
37	055971		Deflector, Chute
38	091921		Mandrel
39	092466		Adapter, Blade
40	17X166		Washer, Belleville
41	17X165		Washer, Hardened
42	15X100		Nut, Hex
43	090828 Z		Pin, Pull
44	017X67 Z		Washer
45	0031X4		Pin, Hair
46	055793E701		Blade, Standard
47			UNKNOWN
	403330		Mower Housing, Complete Includes items 1-47



Ref #	Part Number	Qty	Description
1	015X84		Locknut, Flange
2	017X53		Washer
3	030X20		Pin, Cotter
4	26X249		Screw
5	009X39		Bolt, Shoulder
6	021920		Nut, Adjusting
7	092698		Grip, Blade Control
8	56031E701		Lever Assembly, Lift
9	091573		Grip, Lift Lever
10	055927 Z		Attachment, Clutch
11	001X76		Bolt, Hex
12	015X66		Locknut
13	015X89		Locknut, Flange
14	055853		Cam, Blade Control
15	56224E701		Plate, Left Suspension
16	26X249		Screw
17	015X88		Locknut, Flange
18	002X64		Bolt, Carriage
19	55326E701		Strut, Frame
20	55270E701		Plate, Mounting
21	55346E701		Rod Assembly, Rear Suspension
22	0009X4		Bolt, Shoulder
23	0031X4		Pin, Hair
24	55344E701		Plate, Adjusting
25	24839E701		Rod, Lifter
27	55957E701		Rod, Suspension
28	024471 Z		Clevis
29	0015X2		Nut, Hex
30	055271 Z		Link, Blade Drive
31	017X48		Washer
32	55930E701		Rod and Arm Assembly
33	165X67		Spring, Extension
34	55179E701		Link, Front Deck
35	55139E701		Bracket, Front Suspension
36	56511E701		Lever, Pedal
37	17X122		Washer
38	055298		Clevis
39	015X73		Locknut, Hex
40	009X17		Bolt, Shoulder
41	56023E701		Plate, Right Suspension
42	001X45		Bolt, Hex
43	56595E701		Plate, Index



Ref #	Part Number	Qty	Description
1	92076		Steering Wheel
3	01X102		Bolt, Hex
4	015X88		Locknut, Flange
5	91444C		Post, Steering
6	015X88		Nut, Hex
7	017X47		Washer
10	26X267		Screw
11	56224E701		Plate, Left Suspension
13	56023E701		Plate, Right Suspension
14	001X69		Bolt, Hex
15	56231E701		Support, Front Axle
16	030X49		Pin, Cotter
17	055003		Bearing, Spindle
19	056057		Gear, Pinion
20	56223E701		Axle Assembly, Front
21	56230E701		Hanger Assembly, Front Axle
22	055168		Bearing
23	56236E701		Sector Assembly
24	56625E701		Rod, Drag Link
25	021031		Ball Joint, Steering
26	015X61		Nut, Hex
27	015X87		Locknut, Flange
28	017X87		Washer
30	017X53		Washer
32	030X20		Pin, Cotter
34	55039E701		Spindle Assembly, Left
35	55026E701		Rod, Tie
36	55038E701		Spindle Assembly, Right
37	056105		Bearing, Wheel Also included with Key No. 40.
38	055700		Tire
39	024373		Valve Stem Also included with Key No. 40.
40	92303-601		Wheel & Tire Assembly
41	17X197		Washer
42	094618		Cap, Hub (Optional)